

## SWITCH ON

Press and hold



Enter PIN:

—



Enter your PIN code.



## MAKE A CALL



Enter phone number.



Call the number

(e.g.: 112 for emergency see p. 9)

## ANSWER A CALL



12345678



Accept.

## END A CALL



End.

## ADD A NAME



Network



Enter phone number.



1234\_



1234\_

◀ Store no. ▶



Name :

—



Enter name



Number :

1234\_



If number is OK



Stored

For Voice dial options  
(see page 13)

## ACCESS TO MENU



Enter or exit the menus.

## NAVIGATION



Move Up or Back.



Move Right.



Move Left.



Move Down or Forward or Validate.

## SWITCH OFF



Press and hold.



When your phone is switched off, you cannot receive calls.

## MENU

FORWARDING	MESSAGES	NAMES	CALLS	EXTRA	SETTINGS	SECURITY
------------	----------	-------	-------	-------	----------	----------

### Forwarding

Always	no reply	If busy	Unreachable	Cancel all		
--------	----------	---------	-------------	------------	--	--

### Messages

Centre no.	Archive	Send	Usual msg.			
------------	---------	------	------------	--	--	--

### Names

Search	View	Add	Own number			
--------	------	-----	------------	--	--	--

### Calls

Delete all	View	Meters				
------------	------	--------	--	--	--	--

### Extra

Stopwatch	Clock	Alarm clock	Calculator	Converter	BioCalendar	Reflex
						Total

### Settings

Register	Key tones	Ringer	Box number	Broadcast		
----------	-----------	--------	------------	-----------	--	--

### Security

Change PIN2	Change PIN	PIN code	Fixed names			
-------------	------------	----------	-------------	--	--	--

# TABLE OF CONTENTS

<b>Games</b>	<b>1</b>	Service center number	17
Biorythm calendar	1	Read new messages	16
Reflex	1	Read archived messages	17
Total	1	Send short messages (SMS)	17
<b>Before you start</b>	<b>2</b>	Emotion icons	18
The micro-SIM card	2	Send short messages from	
The battery	2	phoneboock	19
Insert the micro-SIM card	3	Usual messages	20
Insert the battery	3	<b>Calls</b>	20
Discover your phone	4	View calls	20
Display	5	Delete all calls	21
Entering text	6	View meters	21
Basic functions	7	Reset meters	22
Switch ON/OFF	7	<b>Settings</b>	22
Voice dialling	7	Set up meters	22
Make a call	7	Key tones ON/OFF	23
Answer or reject a call	8	Choose ringer	23
Earpiece volume	8	Cell broadcast	23
Consult last calls	8	View topics	23
Adjust ringer volume	8	Add a topic	24
Emergency call	9	Manual registration	24
Change language	9	Voice mailbox number	24
International call	9	Consult your voice messages	25
Keypad lock/unlock	9	<b>Security</b>	25
<b>Special functions</b>	<b>10</b>	Pin request,	25
Answer a second call	10	change PIN and PIN 2 codes	26
Automatic redial	10	Fixed names	26
Scratchpad	10	<b>Extra</b>	27
Touchtones (DTMF)	11	Alarm clock, (set off/set on)	27
Hide your identity	11	Set clock	28
Setting up Flash Dial	11	Calculator	28
<b>Menus</b>	<b>12</b>	Euro converter	29
Discover the Compass key	12	Stopwatch	29
<b>Names</b>	<b>13</b>	<b>Call forwarding</b>	<b>30</b>
Add a name	13	Forward always to mailbox	30
Add voice dial	13	Forward always to number	30
View names in the name list	14	Cancel all	30
Quick access to names	14	<b>Philips Authentic Accessories</b>	<b>31</b>
Search for a specific name	15	<b>Safety Precautions</b>	<b>33</b>
Road your own number	15	<b>Troubleshooting</b>	<b>34</b>
Delete a name	15	<b>Index</b>	<b>36</b>
<b>Messages</b>	<b>16</b>		

# GLOSSARY

<b>DTMF</b>	Dual Tone Multi Frequency The tones are transmitted by the phone to the network. They are used to interrogate answering machines, transmit codes,...
<b>GSM Network</b>	Global System for Mobile communications. The type of phone network used by your phone.
<b>PIN Code</b>	Personnal Identification Number, this is the secret code of the SIM Card. If you, or someone else, enters the wrong PIN code three times your SIM card is blocked. <b>If this happens, please contact your service provider.</b>
<b>PIN2 Code</b>	Secret code that allows you to access certain SIM card dependent features. If you, or someone else, enters the wrong PIN2 code three times your SIM card is blocked. <b>If this happens, please contact your service provider.</b>
<b>PUK Code</b>	Secret code used to unblock your SIM card if you, or someone else, enters the wrong PIN code three times. <b>This code will be given to you by your service provider.</b>
<b>Roaming</b>	Using your phone in a network other than your home network in your country or abroad.
<b>SIM card</b>	Subscriber Identification Module. This card which is provided by your GSM service provider allows you to make phone calls with your GSM phone. Your phone number is contained inside the card.
<b>SMS</b>	Short Messages Service. This service provided by the operator allows you to send and receive short written messages (Maximum : 160 characters).

## Biorythm Calendar

Predict your or your friends' day.



from "Extra"  
switch to  
"Bio calendar".



Extra

◀ Bio calendar ▶

Biorythm will ask for  
your birth date



Birth date:

dd/mm/yyyy

and the date of the day  
you want to predict.  
Then, discover your  
destiny in terms of



Chance ▶



Love ▶



Energy ▶



Success ▶



Be sure to check your  
battery level before  
and after each game  
in order to ensure  
continuity ...  
Reflex and Total are  
only available in  
Savvy Vogue.

## Reflex

Eliminate those pesty  
scrolling invaders.



from "Extra"  
switch to  
"Reflex".



Extra

◀ Reflex ▶

5

JKL

\*

+

#

=

Shoot with your  
gun (<) located  
on the right-hand  
side of the screen



7 3 8 . . . < 8

4

You have to select the  
same number and be on  
the same line as the  
invader when you shoot.



Change your  
shooter number

or use your keypad

4

GHI

6

MNO



Change line

or use your keypad

2

ABC

8

TUV

Points are tallied each time  
an invader is hit, points are  
lost each time you shoot a  
wrong invader.



BONUS LEVELS await  
the exceptional players

## Total

Find the right TOTAL



from "Extra"  
switch to  
"Total".



Extra

◀ Total ▶

Three difficulty levels  
exist.

Find the total with the  
four given numbers.

4 3 2

4.4.8.9

8+9\*4

Enter numbers on the  
second line of the screen:  
Add, subtract,  
multiply or divide.



To find the  
result.

Ask for help and  
your mobile gives  
the beginning of  
the operation.

The game is played in 10  
rounds.

The score depends on :

- time spent,
- number of jokers asked for
- number of wrong attempts.



The player can exit the  
games at any time by  
tapping "Menu" on  
the keypad.


A player answering an  
incoming call while  
playing "games" will  
automatically switch  
the game off.

From your card, remove the micro-SIM card

## ***The micro-SIM card***


To use your phone, you must insert a valid micro-SIM card supplied by your GSM network operator. When you switch the phone on, it may ask for the PIN code. The PIN code is the secret code of the micro-SIM card.

The micro-SIM card contains your subscription number and phone number. It also contains a memory in which you can store phone numbers and messages. If you use your micro-SIM card on another phone, you still retain the same phone number, stored numbers, and messages.



## ***The battery***

Your phone is powered by a rechargeable battery.



- After you plug in the battery, please wait a few seconds before pressing the on/off key to switch the phone on.
- A battery only reaches its maximum capacity after being totally discharged and recharged 2 or 3 times.
- A battery lasts longer if you allow it to fully discharge from time to time.
- If you do not use your phone for several days, it is better to remove the battery.


## ***Remove the battery cover***

Press on the latch on the back of the phone and lift off the battery cover.



## ***Remove the battery (if necessary)***


Lift up on the bottom of the battery and remove it from the phone.




**Insert the micro-SIM card**

First, place the micro-SIM card into the appropriate slot in the battery compartment (the clipped corner should be at the top left).


Then, slide the card with your finger until it stops.

**Insert the battery**


1. Keep the battery + and - on the top facing the + and - of the phone.
2. Slide the battery onto the contacts points and press.

**Replace the battery cover**

Hook the battery cover onto the hinges on bottom of phone and press forward until the latch catches.

**Charge the battery**

With the battery inserted in the phone, plug the connector into the right socket at the base of the phone. Next, plug the transformer unit into an AC power socket.



The only way to turn off the charger is to unplug it, so use an easily accessible AC power socket.

The battery icon on your phone's display indicates the state of the charge process:

- Bars moving = battery is charging.
- Bars steady = battery is fully charged.
- Battery outline flashing (see Troubleshooting p. 33).

You can switch the phone on and use it during charging.

Do not wait for an empty battery to charge your phone again in order to save battery capacity.



*The first time you charge the battery and later, if it is completely discharged, the battery icon will only appear 2 to 3 minutes after you connect the charger. Please charge the phone for a minimum of 3 hours before first use.*

# DISCOVER YOUR PHONE

## "Compass" key

use this key to navigate in the menus, the OK key is used to validate information

**Earpiece**  
listen here

**Antenna**

**Display**  
see next page

## Green "CALL" key

press this key to dial the number or name on the display, or use it to answer a call

## Red "ON/OFF" key

a long press on this key switches the phone on/off, a short press ends a call

## "CLEAR" key


to delete numbers and letters on the display


**Red MENU key**  
to enter and exit the menus

## Keypad

to enter numbers and text

**Microphone**



If you encounter the  symbol in this manual, it means that you have to press and hold the key to activate the function.



## New text message(s)

- if on: you received new messages  
- if flashing: the memory is full, you need to delete old messages before you can receive new ones

## Silent mode

if on: phone will not ring or beep (except for the alarm clock)

## Network

if on: your phone is registered to a network  
if flashing: registration is in progress

## Battery level

the bars indicate the battery level (4 bars is full, no bars means recharging is needed)

## New voicemail


if on: there are new messages waiting in your voicemailbox (\*)

## Roaming

your phone is registered to a foreign network

## Reception quality

the more bars are shown the better the reception



## Arrows


indicate in which directions you can go using the Compass key

## Cursor

indicates that you can enter numbers or text

## Graphics area

displays the clock and guides you through the menu



## 2 text lines




to enter numbers and text or to read text messages













(\*) Depending on the network.

# ENTERING TEXT



Each key allows you to obtain several characters. You have to quickly press the same key several times to reach the desired character.





Example:

TO OBTAIN	Space	D	ü
PRESS	 Once	 Once	 Five times quickly

Key	Characters
	space 1 @ # = < > ( ) & £ \$ ¥
	a b c 2 à ä å æ ç
	d e f 3 é è Δ Φ
	g h i 4 Γ Ì
	j k l 5 Λ
	m n o 6 ñ ò ö ø
	p q r s 7 β Π Θ Σ
	t u v 8 ü ù
	w x y z 9 Ω Ξ Ψ
	. 0 " ' ? ! , ; i ÿ
	* + - / %
	upper-case lower-case mode

While you enter text your phone changes between upper-case and lower-case automatically.

If you wish to enter text in the upper-case mode press , to enter text in the lower-case mode press  again.

The   icons will show that you are in the upper-case mode. In the lower-case mode the   icons appear.



## Switch on/off...

...

## Make a call

### SWITCH ON



**Press and hold.**



Enter PIN:

—

Sometimes entering the PIN code is not necessary (depends on your subscription and on your PIN request settings - see page 25).



**Enter your PIN code.**

The digits entered are replaced by big dots.



If you enter a wrong code 3 times your card will be blocked. If this happens, contact your operator.



PIN correct



If this is the phone's initial use or if the battery has been removed since the last use, you will need to re-set the clock (see page 28).



Registering



Network

### SWITCH OFF



**Press and hold.**



Goodbye

### Voice dialling

You can also make a call by pronouncing the voice tag you have associated to a number (see p. 13).



**Press and hold**



Speak now

Pronounce the name you have associated to the number. The phone dials automatically the number.



Network



**Enter phone number**



01456—



**Call the number**



Calling

0145678901



Black Jack

00:02

Display shows a call cost if sent by your network.




The name will be displayed only if the name is stored in your phone's Names list.

### END CALL



# BASIC FUNCTIONS

## Answer or reject a call



The caller number is displayed only if your subscription supports caller line identification. If the number is in your Names list, the name will appear instead.




Accept the call  
or




Reject the call.

## Earpiece volume


While on a call you can adjust the earpiece volume.



Raise earpiece volume.  
OR



Lower earpiece volume.




## Consult last calls

Your phone automatically stores a list of the last 10 calls you dialed and the last 10 callers who dialed you (including missed calls).



Display the last call made, received or missed.



To view other calls.



To call.



For information on viewing the last 20 calls you placed or received, see "Calls Section" p. 20.

## Adjust ringer volume and vibrator

You can select the vibrator options and adjust or turn off the ringer volume



Display ringer volume selection.




■ Silent ♦ Vibrator ♦ Vibra+ring ♦  
Low ♦ Medium ♦ High ■



Select the volume.



OR  
Select vibrator mode



Validate vibrator or volume selection.

## Emergency call



Enter 112



Calling  
112



Depending on your network operator, the emergency number 112 can be dialed without the micro-SIM card inserted.

## Change language

Normally your phone automatically selects the right language for your country, but in case you want to change it:



Press and hold.



Language

English ▶



Select language.



## International call



To make an international call, you can use "+" as the international prefix.



Network



Press and hold.



+ \_

Dial the number (international country code and local number).



Call the number.



Calling

+831234567

## Keypad lock/unlock

Avoid undesired keystrokes when the phone is in your pocket or purse.



Network



Press and hold to lock keypad.



Keypad is locked



Network



Press and hold to unlock keypad.



Keypad is unlocked




When the keypad is locked, it is possible to dial the emergency number and to receive calls.

# SPECIAL FUNCTIONS

## Answer a second call (Call Waiting)



*This feature depends on the network. If a second person calls you, you will hear a beep. Check the display for a second call.*



**Reject second call**

**OR**



**Accept second call**

**Call 1 is put on hold.**




**Switch between Call 1 and Call 2.**




**To end the call on display and return to other call.**

**Return to single call state.**




## Automatic redial

*When you dial a number and your correspondent is busy, your phone offers the function of automatically redialling.*




**Call failed or recipient is busy.**




**Confirm. OR**

**Any other key cancels autoredial.**



**A beep will sound for each redial attempt or vibrate 5 seconds in both vibrator modes**




**A beep informs you when the connection has been made. An incoming call or any use of the phone will end automatic redial.**


## Scratchpad

*The scratchpad feature is useful if you want to store a telephone number during a call.*


*The number can be dialled or viewed later.*



**Enter the number you want to keep.**



**The display automatically returns to your call.**



**End the call.**



**Call the number on the scratchpad.**

**OR**

**For options.**



## Touchtones (DTMF)

During a call or in direct dialling, the numeric keys always transmit DTMF tones (Dual Tone Multi Frequency) also known as "touchtones".

These tones are used to operate services that you can reach with your phone, like a pager or an answering machine.

Example, to consult your home answering machine:



Enter telephone number of your home answering machine.

	0123456789_
	,



Enter a "wait" signal to give time for the phone to connect.

	0123456789w_



Enter the password of your home answering machine (e.g.: code: 9876).

## Hide your identity



Enter "pause" character.

	0123456789w9
	876p_



Enter code to listen to new message (e.g.: code 3).

	0123456789w
	876p3_



Call.

## Hide your identity

If you type #31# followed by the phone number you call, your phone number is hidden to the other person.

	#31#0123456
	78_



Availability of this feature depends on your network.

## Setting up Flash Dial

You can associate 8 names in the Names list or FDN list with keys 2-9 on the keypad. A long press on one of these keys will automatically dial the associated number.

	Names
	◀ Vincent ▶

Choose the name you want to make Flash Dial.



Press and hold to link the name to key 4.

## CANCEL FLASH DIAL

	Names
	◀ Vincent ▶



Press and hold to cancel link.

## TO FLASH DIAL

	Network



Press and hold to dial linked number.

The Compass Key is your navigator while in the menus.

Press  to enter or exit the menus.

Move one menu-level back.

Switches to option on the left.



Switches to option on the right.








Move forward  
or validate the displayed option.

Here's an example:

*What you see on the display*

*Press this key*

*The Names list menu options*





## Add a name

With your phone, you can store the names and phone numbers of people you call frequently.

MENU



Menu

Names



Names

View

Switch to  
"Add".



Names

Add

Accept.



Name :

—

Enter name  
(max 11  
characters).

For example: Jim

J

I

M

5

JKL

Once

4

GHI

Three  
times  
quickly

6

MNO

Once

...



Delete one  
character.

OR



Press and  
hold to  
delete all  
characters.



Name :

Jim



Number :

—

Enter number  
(20 digits  
max).



Number :

0123456789

Accept  
number.



## Add Voice Dial

NO VOICE DIAL



Voice dial

Yes



Select "No"



TO ADD VOICE DIAL



Press OK  
and speak



Pronounce  
the voice tag  
you want to  
associate to  
the number



Press OK  
and speak



Repeat the  
voice tag you  
want to  
associate to  
the name




Stored



When Voice dial  
memory is full  
(10 names) the  
Voice dial menu  
disappears

# MENUS / NAMES...

View names  
in the Names list



...

For example:

7  
PQRS

Press to jump to  
names starting  
with "P", "Q",  
"R" or "S".



Names  
Philippe



Press to jump to  
next name.



Names  
Rozenn



Call the  
number.

OR



To view the  
number.




0123456789




To view the  
available  
options.


Quick access  
to names..





## Search for a specific name


**MENU**

 Menu  
◀ Names ▶


 **Accept.**

 Names  
◀ View ▶

 **Switch to "Search".**



 **Accept.**

**Example:**


 Search for:  
Ur\_


**Enter first few letters of name**


**U** **R**

**Twice quickly** **Three times quickly**


 **Accept.**


 Names  
◀ Urszula ▶


 **Call name on display.**


## Read your own phone number


**MENU**


 Menu  
◀ Names ▶


 **Accept.**

 **Switch to "Own number".**


 Names  
◀ Own number ▶


 **Accept.**


 Own number  
0123456789


 **Only available if present in the SIM card.**


## Delete a name


 **To access directly to phonebook**


 Names  
◀ Axel ▶


 **Select name you want to delete**


 Names  
◀ Xavier ▶


 **"Accept twice"**


 Xavier  
◀ Send msg. ▶

 **Go to delete**

 **Accept.**

 **Press C to delete**

 **Accept.**

 Deleted


# MENUS / MESSAGES..

## Messages


With your GSM phone you can receive text messages (SMS) and send messages to other GSM phones. To have the possibility of writing and sending messages, you need to enter a service center number first. If it is not present in the SIM card, ask your network operator for it.



Switch to  
"Messages".



Switch to  
"Centre no."



Enter number.



## New message(s)

Your phone allows you to send or receive short written messages.

### NEW MESSAGE INDICATORS



Lights up on the display when you receive a text message. Flashes when the message memory is full. If this happens, you need to delete archived messages otherwise new ones will be rejected.

### READ NEW MESSAGE(S)



Network  
2 msg. ▼




Messages  
1 of 2 ▶

OR




...



Switch to  
"Messages".



Read the  
message.



Scroll  
through the  
message.



To switch  
to other  
messages.

# MENUS / MESSAGES...

Read archived  
messages

Send short messages  
(SMS)



At the end of  
a message.



Delete ♦ Reply ♦ Forward ▮



Switch to  
the option  
you want.



Accept.



When you receive  
a text message  
that comprises a  
telephone number  
enclosed between  
double quotes (e.g.:  
"+33900112233"),  
then the number is  
automatically  
extracted and  
stored in your calls  
list so that you can  
call it back easily.

Messages you have read  
and messages you have  
saved can be found in  
the Archive.




Switch to  
"Messages".



Switch to  
"Archives".



Accept



Switch to the  
message you  
want to read.



Read the  
message.



To switch  
to other  
messages



Menu

◀ Messages ▶



Messages

◀ Send ▶



Accept



Enter phone  
number or select  
a name from the  
phonebook by  
pressing OK a  
second time.



To number:

0123\_




Text:

—

Enter message  
(maximum 160  
characters).  
See "Entering Text"  
section page 6 for  
instructions.




...





Icons


None ▶


Select the icon you want to send. (See "Emotion Icons" table at the end of this procedure). If you do not want to send an icon, choose "None".


Select a category


Validate.


Select icon


Validate.





Send

◀ Yes |

◀ No ♦ Yes ▶

Decide to send or not.






Requesting


Wait while message is being sent.

## Icons

Confirmation will appear.



Sent



Save






◀ Yes |

◀ No ♦ Yes ▶



Decide to save or not.

**IMPORTANT!**  
To see the icon the receiver needs a new Philips phone: Savvy Vogue, Ozeo or Xenium; otherwise the equivalent code will be displayed at the end of the receiver's message.

## Emotion Icons

Icon	Code sent
	Smile :-)
	Wink ;-)
	Cool B-)
	Pfrrt... :-P
	Sad :- (

...

	Grrr	: - /
	Love	( O )
	Broken	( X )
	Yo!	Yo!
	Well done	==b
	BOOM!	> * <
	Deadly	% - I
	Magic	= : I
	Hugging	Ω Ω
	Kiss	: - X
	Idea	? - )
	Sleep	Zzz
	Trapped	: - I
	Failed	==p
	Police	: - !
	Smell!	& @ *

Send SMS from  
phonebook

## Events Icons

	Party	o<I
	Hooray!	iii
	Gift	I EI
	Drink	>-I
	Coffee	I D
	Holidays	-Y-
	Cloudy	;::
	Sunny	>o<
	Flowers	@>-
	Money	\$\$\$
	Snowman	<:7
	Music	Σ-)
	Shopping	\$-)
	Lunch	(II

## Animals Icons

	Miaaaw!	:<*
	Whoof	:>#
	Teddy	8<)
	Monkey	8:)
	Fish	<--<
	Bug	(x)
	Dragon	:>>

## Sports Icons

	Ball	(I)
	Shoot	0-/
	Goal!	(I)
	Victory	:>->
	Red card	II!
	Racquet	o--
	Boarding	o-o
	Golf	o-)

You can also send an SMS directly from your phonebook without having to enter the phone number.

	Network
--	---------



	Names:
	Anders ▶



	Names
	◀ Sebastian ▶



Accept  
twice

	Sebastian
	◀ Send msg. ▶



	Text:
	—


Enter message (maximum 160 characters).  
See "Send short messages (SMS)" for more instructions.





# MENUS / CALLS...


...


**OR**


 Menu  
◀ Messages ▶


 Accept twice

 To number:  
—


 You have direct access to the phonebook

 Select the name

 Accept twice.


 Text:  
—


Enter message (maximum 160 characters). See "Send short messages (SMS)" for more instructions.





## Usual Messages


Your phone contains a number of pre-defined text messages like:  
"Please call me back"  
"I will be late"  
"I will call you back", etc.


 From Messages switch to "Usual msg."


 Messages  
◀ Usual msg. ▶


 Accept


 Usual msg.  
▶ Please call ▶


 Switch to the desired message.


 Accept


 To number:  
—

 Enter number.

 Accept


 Please call me back\_


 Change text (if wished).


 Accept.


## View calls...


You can consult the last 20 calls in the Calls list.




 Switch to "Calls".





 Menu  
◀ Calls ▶

 Accept

 Calls  
◀ View ▶







The Icon indicates the type of call.


-  Phone number you dialed.
-  Phone number of answered call.
-  Phone number of call you missed.
-  Phone number extracted from an SMS message.





...

 **Calls**  
Barbara ▶



 To view other calls,  
 To call,  
OR  
 To view the number.

 0123456789  
▼

 To options.


 Barbara  
◀ Store no. ▶


Delete ♦ Store no ♦  
Send msg. ♦ Usual msg. ▮


 Choose other option if you wish.  
 Confirm selection.


## Delete all calls


You can delete all the calls in the calls list.


 Switch to "Calls".


 Menu  
◀ Calls ▶


 Accept.

 Calls  
◀ View ▶


 Switch to "Delete All".


 Calls  
Delete all ▶

 Accept.

 Press C to delete


You must confirm the deletion.


 To delete.


 Deleted


## View Meters


Your phone has meters that allow you to see the total cost of your calls. It also allows you to set limits on cost and check your consumption.


 **Calls**  
◀ View ▶


 Switch to "Meters".

 Calls  
◀ Meters ▮

 The cost counters and limits will only work if the network supports this feature.

 Meters  
◀ Show ▶



 Show  
Duration ▶

▮ Duration ♦ Remaining ♦ Cost ▮

# MENUS / SETTINGS...

## Reset meters



Switch to the meter you want.



Accept.



Duration  
00:55:26

## Reset meters



Meters  
◀ Show ▶



Switch to "Reset".



Accept.



Reset  
Duration ▶



Select "Duration" or "Cost".



To reset.



For some of these options you might need your PIN or PIN2 code (depending on your operator).

## Set-up meters



From Meters switch to "Setup".



Meters  
◀ Setup ▶



Enter PIN:



Type your PIN code (or more often, your PIN2). Depending on the network.



Currency  
\_



Press and hold to clear your entry.



For example BEF (Belgian francs).

...



Currency  
BEF\_



Price/unit:  
\_

For example 2.50 francs per unit.



Price/unit:  
2\_



Press and hold for the decimal point.



Price/unit:  
2.5\_

## Key tones ON/OFF

Each time you press a key, a tone is emitted. You can silence the key tones by turning them off.

MENU

Switch to "Settings".

From Settings switch to "Key tones".



Settings  
◀ Key tones ▶



Key tones  
◀ Set off ▶

Set off ♦ Set on



Accept.



Set

## Choose ringer

When your phone rings, it plays a melody. You can change this melody.



Settings  
◀ Ringer ▶



Ringer  
Special ▶

## Current melody

For other melodies.



Ringer  
◀ Fortissimo ▶

Phone plays the melody.



Accept.



Set



The «Key tones» and «Ringers» menu items are not visible when the volume is set to "Silent" or "Vibrator"

## Cell broadcast

The broadcast menu allows you to activate or deactivate the reception of SMS broadcast by the network.



From "Setting" switch to "Broadcast"



Settings  
◀ Broadcast ▶



Accept.



Broadcast  
◀ Topics ▶

Reception ♦ Topics ♦ District



The topics menu allows you to define the type of message you want to receive.

## VIEW TOPICS




Accept.



Topics  
View ▶

View ♦ Add



This fonction allows you to view which topics are registered in your phone (e.g: weather report). To delete or change a topic in the topics list use delete or change options.

## ADD A TOPIC

	Topics
	◀ Add



Accept.

	Names:
	—

Enter the name you want to associate with the topics.



Accept.

	Enter code:
	—

Enter the code given by your network operator for this topics.



Accept.

## RECEPTION

The reception menu allows you to activate or deactivate the reception of registered topics.



From Broadcast switch to "Reception"

	Broadcast
	◀ Reception ▶



Accept.

	Reception
	◀ Set off

Set on Set off



Select the desired option.



Accept.

## DISTRICT

The district menu allows you to select a topic from the topics list, which you would like be permanently displayed.

As a result, for this special handling of messages you must enter the topic in both the district menu and the topics menu.

	Broadcast
	◀ District



Accept.



This menu may not appear. Depends on your subscription.

## Manual registration

When travelling abroad, it may be useful to manually register with a network of your choice.



From Settings switch to "Register".

	Settings
	◀ Register ▶



	Requesting

	Register
	◀ Net A ▶



Switch to desired network.



Accept.



Your phone will revert to automatic network selection next time you switch it on.

# MENUS / SECURITY...

## Voice Mailbox number

To be able to use Voicemail you need to set up your voice mailbox number.

Ask your network operator for this number.



From Settings switch to "Box number".



Settings

◀ Box number ▶



Box number:

—



Enter number.



To correct (if needed).



This menu may not appear. Depends on your subscription.

## Consult your voice messages



Lights up on the display if you have a new voice message.

Availability of this feature depends on your network.



Press and hold to call for your voicemail.

OR



Network

Consult ▼



Voicemail

0123456789



To call.

## Pin request



Switch to "Security"



You can (de)activate the request for the PIN code at power-on.



Security

◀ PIN code ▶



PIN code

■ Set off ▶

■ Set off ♦ Set on ■



Switch to desired option.



Enter PIN:

—




Enter the PIN code.





Deactivated


# MENUS / SECURITY...


## Change PIN and PIN 2 codes


 Security  
◀ Change PIN ▶


 Accept.


 Old PIN:  
—


 Enter old PIN code.


 OK


 New PIN:  
—


 Enter new PIN code.

 Accept.

 Repeat PIN:  
—

 Enter new PIN code again.


 Accept.


 Changed  
—


## Fixed names


Your network operator may have provided you with a SIM card which supports fixed names (FDN). You can restrict the use of your phone to the numbers stored in the fixed names list.

VIEW FIXED NAMES


 From Security switch to "Fixed names".


 Security  
◀ Fixed names ▶


 OK

 Fixed names  
◀ View ▶


Search ◀ View ▶ Add ▶ Restrictions ▶

 OK


 Fixed names  
Thomas ▶


 To view other names.


OR


 To call.


## Add names


 From "Fixed Names" switch to "Add".


 Fixed names  
◀ Add ▶


 OK


 Enter PIN2:  
—


 Enter PIN2.


 Name:  
—


 Enter name.

 OK

 Number:  
—

 Enter number.

 OK

 Stored  
—

## Restrict to fixed names

From "Fixed Names" switch to Restriction.

Fixed names  
◀ Restriction ▶

OK

Restriction  
◀ Set on ▶

Set off ♦ Set on

OK

Accept.

Enter PIN2:  
—

Enter PIN2:

OK

Activated

If «Restriction» is activated, then only the numbers in the fixed names list can be called.

## Alarm

The phone offers you some fun and practical functions.

MENU

Switch to "Extra"

OK

ALARM

Your phone has a 24 hour alarm clock. The alarm will ring even if the phone is switched off. When the alarm rings press any key to silence it.

SET ALARM OFF

Extra  
◀ Alarm clock ▶

OK

Alarm clock  
Set off ▶

Set off ♦ Set on

OK

Deactivated

## Set alarm on

Extra  
◀ Alarm clock ▶

OK

Alarm clock  
◀ Set on ▶

Set off ♦ Set on

OK

Alarm Clock  
◀ 18:44 ▶

> Minutes decrease  
< Minutes increase

OR

Enter hour and minutes (eg: 07:45).

OK

Set

# MENUS / EXTRA...

## Set clock



From Extra switch to "Set clock".



Extra

◀ Set clock ▶



Set clock

◀ 11:37 ▶



< Minutes decrease

> Minutes increase

OR



Enter hour and minutes (eg: 19:42).



Set clock

◀ 19:42 ▶



Accept.



Set



You have to set the clock if you remove the battery.

## Calculator

Your phone has a calculator to add (+), subtract (-), multiply (\*), and divide (/).



Network



Press and hold to use calculator.

OR



from Extra switch to "Calculator".



Extra

◀ Calculator ▶



Calculate:

0\_

To	+	-	*	/
PRESS				
	Once	Twice	Three times	Four times

For example  
 $3 \times 6 = 18$



...



Calculate:

3\_



Calculate:

3 \* \_



Calculate:

3 \* 6\_



Calculate:

=18



To clear.



Press and hold zero to enter a decimal point.



## Euro converter

This feature is only available for countries participating in the European Monetary Union. It allows you to easily convert Euros into your local currency and vice versa.



From Extra switch to "Converter".



Extra  
◀ Converter ▶



Converter  
Euro → FF ▶

■ Euro → FF ♦ FF → Euro ■



Switch to desired type of conversion.



Euro:  
—



Enter amount (e.g.: 10.5 Euros).

...



Euro:  
10.5



10.5 Euro  
66.75 FF




Press and hold zero to enter a decimal point.

## Stopwatch

You can time a race or other event.

This stopwatch is not a professional measuring device. Its measurements cannot be applied in an official context.



From Extra switch to "Stopwatch".



Extra  
◀ Stopwatch ▶



Stopwatch:  
00:00:00.00



Start the stopwatch.



Stop the stopwatch.



Restart the stopwatch.



Reset the stopwatch to zero (when stopped).

# MENUS / CALL FORWARDING...

## Call forwarding

Depending on your network operator your phone will allow you to divert all your calls to voicemail or to another number. You will have to select the type of forwarding you want .

MENU

Switch to  
"Forwarding"



Menu

Forwarding ▶



Forwarding

◀ If no reply ▶

Always ◀ If no reply ◀ If busy ◀  
Unreachable ◀ Cancel all ▶

Select the option  
wanted by pressing  
the OK key



Example : Always  
FORWARD ALWAYS  
TO MAILBOX



Forwarding

Always ▶

Status ◀ Cancel ◀ To mailbox ◀ To number ▶



Switch to  
mailbox



...



Requesting



Activated

Your phone will not ring  
as long as your calls  
are forwarded to your  
mail box.



To be able to forward  
calls to your voice mail  
check that your mail box  
number has been set  
correctly ( see "Settings"  
section page 25)

FORWARD ALWAYS TO  
NUMBER



From  
"Forwarding"  
switch to  
"Always"



Forwarding

Always ▶



Select "To  
number"



Number :

—

## Cancel all



Enter the  
number to which  
you want to  
divert your calls



Requesting



235

Activated



"Status" will show you  
if this specific call  
forwarding option is  
activated or not .  
You can cancel each  
individual forwarding  
option by using "Cancel"  
instead of "Cancel all"

CANCEL ALL



From "Forwarding"  
switch to  
"Cancel all"



Forwarding

◀ Cancel all ▶



Deactivated

Your phone will now  
receive calls as normal ;

*"When Performance Counts... Philips Authentic Accessories are Designed to Maximize the Performance of Your Philips Phone".*

## **PLUS Battery**

### **Reference**

BHR 130/P	9911 240 32041
NiMH	1300 mAh



## **SLIM Battery**

### **Reference**


BHR 127/P	9911 240 32040
NiMH	700 mAh



## **Cigarette Lighter Adapter 12V - 24V**

### **Reference**

CKLR 12/P	9911 240 34118
-----------	----------------



## **Deskstand Charger**

Compact and convenient solution for charging and standing your phone ready for use.

### **Reference**

DTSC 12/P	9911 240 35143
-----------	----------------



## **Fast Travel Charger**

### **Reference**

Europe	ACSR 12/P	9911 240 30042
Taiwan/USA	ACTR 12/P	9911 240 30043
UK	ACUB 12/P	9911 240 30044
Australia	ACAR 12/P	9911 240 30045



## **Fast Battery Charger and Conditioner**

The cradle holds a single battery. Four versions of AC plugs available.

### **Reference**

Europe	DTER 12/P	9911 240 35137
Taiwan/USA	DTTC 12/P	9911 240 35139
UK	DTUC 12/P	9911 240 35140
Australia	DTAC 12/P	9911 240 35141



# PHILIPS AUTHENTIC ACCESSORIES

## **Basic Car Kit**

Keeps your phone secure and within easy reach while the battery is charging.

### **Reference**

CKBR 12/P 9911 240 34210



## **Car Kit with Headset**

Enjoy hands-free conversation while your phone is secure and within easy reach.

### **Reference**

CKSR 12/P 9911 240 34211



## **Compact Car Kit**

Easy to use, this very compact hands-free solution offers a high audio quality while also charging your mobile.

### **Reference**

HSSX 15/P 9911 241 30018



## **Headset**

Use your phone under almost any situation with this convenient hands-free, very mobile solution.

### **Reference**

HSLB 12/P 9911 241 30023




## **Deluxe Hands-Free Headset**

Additional in line answer button offers you a simplified alternative to searching for the phone keypad.

### **Reference**

HSLD 15/P 9911 241 30024



## **Personal Accessories**

Keeps your phone within easy reach, safe and secure.

### **Reference**

Carry Case with Belt Clip PBCR 12/P 9911 240 37023

Belt Clips (3 colors per package) VBCR 12/P 9911 241 39203

Phone Necklace VPNR 12/P 9911 241 39204



## **Easel-Style Phone Stand**

Keeps the display on your phone at an easy-to-read angle.

### **Reference**

VPER 12/P 9911 241 39205



Ask for Philips Authentic Accessories where you bought your Philips phone.

## RADIO WAVES


- Your phone transmits/receives radio waves in the GSM frequency (900/1800 Hhz).
- The GSM network controls transmission power (0.01 to 2 watts).
- Your phone complies with all relevant safety standards.
- The CE mark on your phone shows compliancy with European electromagnetic compatibility (Ref. 89/336/EEC) and low voltage directives (Ref. 73/23/EEC).

## SAFETY PRECAUTIONS

- Careless use can cause harm to you and others.
- Please inquire and respect local laws and regulations.
- Use your phone in the normal operating position (to ear).
- Avoid touching the antenna while a call is in progress.
- Do not use your phone if the antenna is damaged (risk of minor skin burn).
- Keep your phone in a safe place, out of reach of small children.
- Check with other manufacturers that consumer electronics will not be affected by radio energy.
- Avoid use of phone while driving. It affects your concentration.
- Switch phone off in an aircraft. It is illegal to use cellular phones when airborne.
- Switch phone off near hospitals or medical equipment.
- Ask manufacturer about radio wave shielding of electronic medical devices you may use (pacemaker, hearing aid).
- Switch phone off where blasting is in progress (for example in quarries).
- Switch phone off in potentially flammable atmosphere (petrol stations, fuel depot, chemical plants).



## ENVIRONMENTAL CARE

- Please remember to observe the local regulation regarding the disposal of your packaging material, exhausted batteries and old phone and where possible promote their recycling.



- *The phone must ALWAYS be switched OFF by pressing the Red ON/OFF key and never by removing the battery while the phone is ON. Otherwise, the stability of the settings, alarm clock and ring cannot be guaranteed.*
- *The phone is equipped with an alarm clock that, if set, will ring. If the phone is off and the alarm rings, no radio waves are transmitted. Press any key to turn off the alarm.*

# TROUBLESHOOTING

PROBLEM	SOLUTION
<i>The phone does not switch on.</i>	Check if the battery is correctly inserted (big arrow facing you and pointing to the top) and/or charge the phone until the battery icon has stopped flashing.
<i>The display shows "BLOCKED" when you switch on.</i>	Somebody tried to use your phone but did not know the PIN code or Unblocking code. Contact your service provider.
<i>After switching on your phone, the SIM lock code is required (NCK, NSCK, SPCK, CCK, PCK).</i>	Your phone is configured to work only with your service provider's SIM card. Please contact your service provider to get further information.
<i>The  and  symbols are not displayed.</i>	The network connection is lost. Either you are in a radio shadow (in a tunnel or between tall buildings) or you are outside of the network coverage area. Try from another place.
<i>The display doesn't respond (or responds slowly) to key pushes.</i>	The display responds more slowly at very low temperatures. This is normal and does not affect the operation of the phone. Take the phone to a warmer place and try again.
<i>Your phone shows "insert SIM" on the display.</i>	Remove your battery. Check that the micro SIM card is correctly inserted (clipped corner at the top left - see page 3).
<i>Your phone does not display the caller's number.</i>	This feature is subscription dependent. If your subscription does not support it, the phone displays "Call". Please contact your service provider to get further information.
<i>When attempting to use a feature in the menu, the mobile displays "not allowed".</i>	Many features are subscription dependent. They are only available, therefore, if your subscription supports them. Please contact your service provider to get further information.

PROBLEM	SOLUTION
<i>You cannot send messages or your correspondent does not receive your messages.</i>	Some networks do not allow message exchange with other networks. Please contact your service provider to get further information. The network can be crowded and messages can take some time to arrive.
<i>Your correspondent does not receive your emotion icons.</i>	Only Philips phones (see page 18) can receive emotion icons.
<i>The display shows SIM FAILURE.</i>	Your SIM card may be damaged. Please contact your network operator.
<i>The display shows IMSI FAILURE.</i>	The problem is related to your subscription. Please contact your network operator.
<i>Your telephone is wet.</i>	Switch it off and remove the battery (see page 2). Let them to dry separately 24 hours before using it again.
<i>You cannot enter operator services.</i>	Press and hold the "Menu" key. If this does not work, please contact your service provider.
<i>Keys tones or ringer menu have disappeared.</i>	You are probably in Silent or Vibra mode (see page 23).
<i>While charging the battery icon is not displayed.</i>	Your battery is completely empty, please wait a few minutes after connecting the charger.
<i>When charging the battery, the battery icon shows no bars and the outline is flashing.</i>	Only charge the battery in an environment where the temperature does not go below 0°C (32°F) or above 50°C (113°F).
<i>Ear piece volume is too low or too high.</i>	You can adjust it (see page 8).

- Accessories - 31,32
- Alarm - 27
- Battery - 2, 31
- Biorhythm calendar - 1
- Calculator - 28
- Calls - 20
  - Answer a call - 8
  - Answer a second call - 10
  - Call forwarding - 30
  - Emergency call - 9
  - End a call - 7
  - International call - 9
  - Last calls - 8
  - Make a call - 7
  - Menu - 20
  - Reject a call - 8
- Capital letters - 6
- Cell Broadcast - 23
- Clear display - 4
- Clock - 28
- Compass key - 4, 12
- Consult last calls - 8
- Display - 5
- DTMF tones - 11
- Earpiece volume - 8
- Emergency - 9
- Emotion Icons - 18
- Entering Text - 6
- Euro Converter - 29
- Extra - 27
  - Alarm - 27
  - Biorhythm calendar - 1
  - Calculator - 28
  - Clock - 28
  - Euro Converter - 29
  - Reflex - 1
  - Total - 1
  - Stopwatch - 29
- Fixed names - 26
- Flash Dial - 11
- Forward calls - 30
- Games - 1
- Hide identity - 11
- Keypad - 4
  - Lock - 4,9
  - Unlock - 4,9

- Languages - 9
- Last calls - 8
- Mailbox number - 25
- Manual registration - 24
- Menus
  - Calls - 20
  - Extra - 27
  - Messages - 16
  - Names - 13
  - Security - 25
  - Settings - 22
  - Voicemail - 25
- Messages - 16
  - Cell Broadcast - 23
  - Menu - 16
- Meters - 21
- Micro-SIM card - 2
- Names - 13
  - Add a name - 13
  - Menu - 13
  - Fixed names - 26
  - Search a name - 15
  - View list - 14
- Phone - 4
  - Own number - 15
- PIN - 25
- Ringer volume - 8
- Restrict to FDN - 27
- Scratchpad - 10
- Safety Precautions - 33
- Security - 25
- Settings - 22
- Set
  - Alarm On/Off - 27
  - Clock - 28
- Set-Up meters - 22
- Switch On/Off - 7
- Stopwatch - 29
- Touchtones (DTMF) - 11
- Troubleshooting - 34,35
- Voice dialling - 7
- Voicemail - 25
- Volume
  - Earpiece - 8
  - Ringer - 8
  - Vibrator - 8